

# STOP WATCH

ZNBK-STWTC2

ZÖN  
FIND YOUR ZONE



## Timing:

Press button "A" until a second number is displayed. If the second number is not Zero, press button "B" to stop timing, then press button "C" to reset the stopwatch to zero.

Press button "B" to start timing, press button "B" again to stop timing.

Press button "C" to reset the stopwatch to zero.

## Display: Time, Calendar, Weekday and Alarm

Press button "A" until the stopwatch is in time mode, then press button "B" to display the month, date and the weekday. Press button "C" to display the alarm time, then press button "B" and button "C" at the same time to sound the alarm, cancel or maintain.

## Set time and calendar:

When the stopwatch is in normal time mode, press button "A" three times.

The second number and the weekday will flash indicating the stopwatch has entered into the time setting mode. Press button "B" to advance to the next number:

Press button "C" to choose seconds, minutes, hours, date, month & weekday.

A is for AM/Morning and P is for PM/Afternoon.

H represents 24 hour mode setting. These are the adjusted objects.

After setting, press button "A" to return to time mode.

## Set alarm:

In the normal time mode, press button "A" twice, time and weekday will flash simultaneously; this indicates the stopwatch is in the alarm mode.

Press button "C" to choose hour and minute, press button "B" to advance the number of the hours and minutes.

Press button "A" to reset back to time mode.

## Set hourly alarm:

In the normal time mode, press button "C", then press button "A", the weekday will display the hourly alarm, if weekday doesn't display, alarm will not set.

## Caution:

- Avoid long exposure in humidity
- Avoid contacting with corrosive materials
- Avoid direct sunlight

## Battery:

Replace battery with 1.5v Alkaline